


Over **11,000** Systems Installed –WORLDWIDE– **ER DRIVER**
MODEL 1400



ITEM	PART NO.	DESCRIPTION
1	182030	HOUSING
2	182032	ROTOR
3	182043	SHAFT, SGL ECCENTRIC
4	182031	END PLATE
5	141023	MECHANICAL SEAL
6	184036	SEAL HOUSING, C-FACE
7	103383	WAVE SPRING WASHER
8	881623	BEARING
9	184004	WASHER, THRUST
10	881882	BEARING
11	881157	BEARING, H.D. DRIVE
12	101045	SNAP RING
13	881999	SPACER
14	103381	SNAP RING

ITEM	PART NO.	DESCRIPTION
15	184037	BEARING CAP
16	881551	SCREW
17	881348	H.C. LOCK WASHER
18	882217	STUD W/NUTS
19	184081-01	KEY, 1/4" SQ. X 1"
20	182027	SLEEVE BEARING
21	182002	WEAR RING
22	882215	DOWEL PIN
23	271248	PLUG, 1/2"
24		
25	882266	O-RING, VITON
26	151005	PLUG
27	882066	O-RING, VITON
28	182016	VANE

For Questions or help in finding a part, Please call a Hammonds Technician at (800) 582-4224



HAMMONDS TECHNICAL SERVICES, INC.
6807 West Little York • Houston, Texas 77040 • (800) 582-4224
www.hammondscos.com